MTCE-10R-NT *MTCE-10T-NT*

1.1 Appearance and terminal





3.1 Ambient temperature

3.2 Installation site

3.3 Installation method

DIN slot installation for the field with little vibration

Screw installation for the field with high vibration



3.4 Cable connection and specification

4.1 Terminal introduction



⏚	

4.2 Wiring



Wiring Requirements

Display Area

5.1 Power-supply Specification

5.2 Performance Specification

Phenomenon	Possible reason	Countermeasures